

Load and Motor Switchgear



STAHL

[Contents]

Safety Switches

8537

10/2 ... 10/9

10 A
 16 A
 25 A
 40 A
 63 / 80 A
 125 / 160 A
 250 A

Load and Motor Switchgear

8511

10/10 ... 10/11

16 A
 25 A

Motor Protection Circuit-Breakers

8527

10/12 ... 10/15

up to 22,5 A

Manual Motor Starters

8525

10/16 ... 10/17

up to 63 A

STAHL